

CFM/CMM Thermo Anemometer

Model AN510



Introduction

Thank you for selecting the Extech AN510 CFM/CMM Thermo-Anemometer. This instrument measures Air Velocity, Air Flow (volume), Air Temperature, and Type K Temperature (external probe). The backlit LCD includes primary and secondary displays plus numerous status indicators. This device is shipped fully tested and calibrated and, with proper use, will provide years of reliable service. Please visit our website (www.extech.com) to check for the latest version and translations of this User Manual, Product Updates, and Customer Support.

Features


- Built-in microprocessor circuit
- Low-friction ball bearing mounted wheel provides high accuracy
- LCD with backlight for easy viewing
- Compact, light-weight, easy to use design
- Wristlet for easy one-handed operation

Safety

Please read the entire User Manual and Quick Start before operating this device. Use the meter only as specified and do not attempt to service or open the meter housing. Do not allow children to handle the meter. Please dispose of batteries and meter responsibly and in accordance with all applicable laws and regulations.


Meter Description

1. Air Velocity vane
2. Type K Temperature probe input
3. LCD Display
4. ON/OFF Power button
5. Backlight and ▲ button
6. MODE button
7. Unit Button
8. SET and ▼ button
9. RECORD button
10. Hold Button




LCD Description

1. Air Velocity
2. Record
3. Max
4. Min
5. Hold
6. Air Flow
7. Battery Indicator
8. Auto Power OFF
9. Unit of Measure
10. Temperature Units
11. Lower LCD Display
12. Upper LCD Display
13. Type K Temperature




Operation

Power

Short press the power  button to power the meter ON or OFF. The meter will begin displaying readings for the mode selected. If the LCD does not switch on, check the batteries located in the rear battery compartment.

Backlight

The LCD is equipped with backlighting for easier viewing, especially in dimly lit areas. Press the  backlight button to turn the backlight on. The backlight will automatically turn off after 10 seconds.


Data Hold




Short press the **H** (hold) button to freeze or unfreeze a reading on the display. The **H** icon and the most recent reading will appear in the display. Hold function will not work while in record mode.

Auto Power OFF (APO)



In order to conserve battery life, the meter will automatically shut off after approximately 10 minutes of inactivity. The APO icon appears in the display when APO is programmed to be ON (see the SET function section later in this manual).

Mode

Press the mode  button to select the mode of operation. Each press of the button will step through the three modes.

1. Air Velocity – Displays the air speed through the vane in the units selected. The  icon will appear in the display. Air velocity will be displayed on the upper part of the LCD. Air temperature will be displayed on the lower part of the LCD while in air velocity mode.
2. Air Flow – Displays the volume of air passing through a duct. The  icon will appear in the display. The duct area must be entered using the SET function for proper measurements.
3. Type K Temperature – Displays the temperature. The  icon will appear in the display. A type K thermocouple must be connected to the meter for Type K temperature displays.

Air Velocity Units

1. Select Air Velocity with the  button.
2. Press the  button to step through and select the desired units. (ft/min, m/s, km/h, MPH, knots)

SET Function

(APO On/Off, Temperature Units and Air Flow Units Settings)

1. Press and Hold the ▼ button for 2 seconds. The yes or no APO display will appear:

YES NO
PoFF PoFF

2. Press the ▲ or ▼ button to turn the APO ON (YES) or OFF (NO).
3. Press the **R** button to save the selection.
4. The temperature units display will appear:

F C
t-[]F t-[]C

5. Press the ▲ or ▼ button to change the degree F or degree C units.
6. Press the **R** button to save the selection.
7. The Air Flow units display will appear:

Unit

8. Press the ▲ or ▼ button to select CMM or CFM units.
9. Press the **R** button to save the selection.
10. Short press the power button or wait approximately 10 seconds for the meter to return to normal operation.




Setting Dimensions for Airflow Measurements

The area of the air duct in square feet or square meters must be entered to perform air flow (volume) measurements. Remember to convert square inches or centimeters to square feet or square meters for area measurements before continuing. See 'Useful equations and Conversions' later in this manual for additional information.

1. Select Air Flow with the **M** button.
2. Press the **SET** button. **F-2** (ft²) or **m-2** (m²) will appear in the display depending on the air flow units selected (CFM or CMM).
3. Press the ▲ or ▼ button to set the area in square feet or square meters in the display.
4. Press the **R** button to save the value.
5. With the area values programmed, measure air flow in the duct to obtain air volume (CFM or CMM) readings.

MAX-MIN Recording

In this mode, the meter records the maximum and minimum values over time.

1. Short press the **R** button to enter the Record mode. The  record icon will appear on the display. The maximum and minimum values will be recorded and updated during the measurement period.
2. Short press the **R** button to stop the Max-Min recording. The  icon and the MAX value that occurred during the recording period will be displayed.
3. Short press the **R** button to display the  icon along with the MIN value that occurred during the recording period.
4. Short press the **H** button to clear the memory and start a new max/min measurement period.
5. Long press the **R** button to exit record mode.

Maintenance

Battery Replacement

1. Power OFF the meter.
2. Remove the flat head screw that secures the battery compartment at the back of the meter.
3. Open the battery compartment and replace the 3 AAA batteries observing correct polarity. Re-assemble the meter before use

Safety: Please dispose of batteries responsibly; never dispose of batteries in a fire, batteries may explode or leak. If the meter is not to be used for 60 days or more, remove the battery and store separately.



Never dispose of used batteries or rechargeable batteries in household waste.

As consumers, users are legally required to take used batteries to appropriate collection sites, the retail store where the batteries were purchased, or wherever batteries are sold.

Disposal: Do not dispose of this instrument in household waste. The user is obligated to take end-of-life devices to a designated collection point for the disposal of electrical and electronic equipment.

Cleaning and Storage


Periodically wipe the case with a damp cloth and mild detergent; do not use abrasives or solvents.

Specifications

| General | | | |
|---------------------------|--|--|----------------------------------|
| Display | Backlit LCD 35 x 30mm (1.38 X 1.18 ") | | |
| Sensor | Air velocity: Low friction ball bearing; Air Temperature: thermistor | | |
| Measurements | Air Velocity, Air Temperature, Air Flow, Type K thermometer | | |
| Tripod mount | On back of meter | | |
| Operating Humidity | 80% RH Max | | |
| Operating Temperature | 0 to 50°C (32 to 122°F) | | |
| Over Limit Display | "- - -" | | |
| Power Supply | 3 x 1.5V AAA batteries | | |
| Power Consumption | Approximately 5mA DC | | |
| Weight | 136g (4.8 oz.) | | |
| Dimensions (HxWxD) | 141x 57x 25mm (5.5 x 2.3 x 1.1 ") | | |
| Air Velocity | | | |
| Units | Range | Resolution | Accuracy |
| ft/min | 80 to 3937 | 1 | ±3% F.S. |
| m/s | 0.4 to 20.0 | 0.1 | |
| km/h | 1.4 to 72.0 | 0.1 | |
| MPH | 0.9 to 44.7 | 0.1 | |
| knots | 0.8 to 38.8 | 0.1 | |
| °C | 0 to 50 | 0.1° | ±1.2°C |
| °F | 32 to 122 | 0.1° | ±2.5°F |
| Air Flow | | | |
| CMM (m ³) | 0.024 to 36000 | 0.001/0.01/0.1/1 | |
| CFM (ft ³) | 0.847 to 1271300 | 0.001/0.01/0.1/1/10 (x10) / 100 (x100) | |
| Type K Thermometer | | | |
| °C | -50 to 1300 -50.1 to -100 | 0.1° | ±(0.4% + 0.5°C) ±(0.4% + 1°C) |
| °F | -58 to 2372 -58.1 to -148 | 0.1° | ±(0.4% + 1°F) ±(0.4% + 1.8°F) |


Useful Equations and Conversions

AREA equation for rectangular or square ducts



$$\text{Area (A)} = \text{Width (W)} \times \text{Height (H)}$$

Area equation for circular ducts



$$\text{Area (A)} = \pi \times r^2$$

Where $\pi = 3.14$ and $r^2 = \text{radius} \times \text{radius}$

Cubic equations

$$\text{CFM (ft}^3/\text{min)} = \text{Air Velocity (ft/min)} \times \text{Area (ft}^2)$$
$$\text{CMM (m}^3/\text{min)} = \text{Air Velocity (m/sec)} \times \text{Area (m}^2) \times 60$$

NOTE: Measurements made in *inches*
must be converted to feet or meters before using the above formulae.

Unit of Measure Conversion Table

| | m/s | ft/min | knots | km/h | MPH |
|----------|---------|--------|---------|---------|---------|
| 1 m/s | 1 | 196.87 | 1.944 | 3.6 | 2.24 |
| 1 ft/min | 0.00508 | 1 | 0.00987 | 0.01829 | 0.01138 |
| 1 knot | 0.5144 | 101.27 | 1 | 1.8519 | 1.1523 |
| 1 km/h | 0.2778 | 54.69 | 0.54 | 1 | 0.6222 |
| 1 MPH | 0.4464 | 87.89 | 0.8679 | 1.6071 | 1 |

Copyright © 2017 FLIR Systems, Inc.

All rights reserved including the right of reproduction in whole or in part in any form

ISO-9001 Certified

www.extech.com